

1. Remove the floor mat and plastic covers covering the front seat hardware.



2. You will need an M10 triple square to loosen the seat bolts. Do NOT fully remove it. You only need enough space to splice the bracket under the factory bolt.



3. Slide the bracket under the bolt & tighten.



4. Mount your fire extinguisher and test clearance. The bracket is offset and made to clear the seat plastics.





